


M843W3

GEM Series Sound Enclosure Assembly Instructions



Corporate Headquarters

4420 14th Avenue NW Seattle, WA 98107 Tel: (206) 789-3880 Fax: (206) 782-5455

Alaska Branch Office

1200 West International Airport Road Anchorage, AK 99519 Tel: (907) 562-2222 Fax: (907) 563-1921

Southeastern U.S.A.

1419 W Newport Center Dr Deerfield Beach, FL 33442 Tel: (954) 421-1717 Fax: (954) 421-1712

East Coast Branch

15 Aegean Dr. Suite 4 Methuen MA 01844 Tel: (978) 475-7400 Fax: (978) 475-7745

Gulf Branch

19 Veterans Memorial Blvd. Kenner, LA 70062 Tel: (504) 360-2180 Toll Free: (800) 843-6140

M843NW3 GEM SERIES SOUND ENCLOSURE

ITEM	DESCRIPTION	NLI P/N	QTY	NOTES		
1	JUNCTION BLOCK OFF PLATE ASSEMBLY	06-73111	1			
2	REAR PANEL ASSEMBLY	06-73102	1	Includes 06-73108		
3	M8 FLAT WASHER	15-11000	4	Loose, bagged		
4	M8 LOCK WASHER	15-00705	4	Loose, bagged		
5	M8 HEX HEAD CAPSCREW	12-00776	4	Loose, bagged		
6	1/4" NPT BRASS PIPE NIPPLE	21-00201	2	Loose, bagged		
7	1/4" NPT BRASS PIPE CAP	21-72241	2	Loose, bagged		
8	SOUND FOAM, SNORKEL RECEIVER SEAL	55-73174	1	Loose, bagged		
9	BOTTOM SIDE VALENCE ASSEMBLY	06-73104	2			
10	FRONT BOTTOM VALENCE ASSEMBLY	06-73108	1			
11	NON-SERVICE SIDE PANEL ASSEMBLY	06-73107	1			
12	SERVICE SIDE PANEL AFT ASSEMBLY	06-73106	1			
13	FRONT PANEL ASSEMBLY	06-73101	1			
14	SEAL BAR ASSEMBLY	06-73110	1			
15	TOP PANEL ASSEMBLY	00-73103	1			
16	SERVICE SIDE PANEL, FWD ASSEMBLY	00-73105	1			
17	GROMMET 1-1/8" ID X 1-7/8" OD	00-70083	2	Loose, bagged		
Specifications:						
Enclosu	e (Installed on Generator Base):					
Length (OA)						
	Width22.6 in (574 mm)					
Height25.8 in (655 mm)						

Assembled Weight:

43 lbs (19.5 kg) shield only

787 lbs (357 kg) with generator set

Prior to assembly, inspect all components for damage. Report any damage to the shipping company. Check the packing list in the back of this manual to be sure all parts are included.

Note: The Generator set features a single point lifting eye. However, the generator may still possess original factory lifting points, which need to be loosened and rotated down, until they are below the highest point of the engine. Be sure to retighten those bolts before moving on.

Select a mounting location in accordance with the guidelines in the IM1000 Installation Manual. The generator set must typically be mounted on a rigid, flat surface above a strong structure, such as the vessel's stringers, to minimize vibration transference to the hull.


Note that the generator set is designed for single side service. When viewed from the rear, the right hand side is the service side and should be exposed for easy maintenance access.


Install the generator set in the vessel as near to a level attitude as possible. Ensure that the enclosure's left hand side and rear are at the recommended distances (6 inch recommended, 4 inch minimum.) from the vessel's bulkheads.


AVOID POSITIONING THE ENCLOSURE INTO CORNERS WITH OVERHEAD BLOCKED TO REDUCE CHANCE OF INTAKE/EXHAUST AIR RECIRCULATION OUTSIDE THE SHIELD.




PRIOR TO SOUND SHIELD ASSEMBLY, START WITH ITEM #1 SHOWN IN THE FOLLOWING ILLUSTRATIONS.















DETAIL D

STEP 5.
INSERT ENGINE AIR INTAKE SNORKEL
HOSE INTO SNORKEL RECIEVER IN REAR
PANEL, UNTIL IT HITS THE STOP.

You may encounter some resistance as the rear panel comes into contact with the air intake snorkel hose. Note that the rear panel has a small hole in the vicinity of the intake snorkel. Guide this hose so that it is inserted in the panel hole, ensure that the hose does not go too far into the rear panel, blocking the hose end. (Generally this hose will install without adjustment at the retaining clamp.)


Note: The Generator set features a single point lifting eye. However, the generator may still possess original factory lifting points, which need to be loosened and rotated down, until they are below the highest point of the engine. Be sure to retighten those bolts before moving on.







DETAIL A

-NOTE PRE-INSTALLED PINS.
GUIDE THESE INTO CORRESPONDING HOLES
IN EACH FRONT/REAR LOWER VALENCE, PUSHING
FIRMLY TO SNAP INTO PLACE. DISPLACED PINS MAY
BE PUSHED BACK INTO POSITION BY USING A LONG
TOOL SUCH AS SCREW DRIVER OR PRY BAR FROM
THE INSIDE. PUSH/MOVE SOUND FOAM OUT OF THE
WAY FOR IMPROVED ACCESS TO PINS.





VIEW: NON-SERVICE SIDE




TIGHTEN WITH HAND TOOLS TO AVOID DAMAGE TO HARDWARE.








TIGHTEN WITH HAND TOOLS TO AVOID DAMAGE TO HARDWARE.













POSITION THE SEAL BAR ASSEMBLY

SEAL BAR INSTALLED


-CAPTIVE THUMBSCREW AFT POSITION.




CAPTIVE THUMBSCREW FORWARD POSITION.













DETAIL B











LOCATOR PIN (ENGAGED) ON SERVICE SIDE PANEL ASSEMBLY, 2 PLACES-



DETAIL B




Install connections for exhaust, AC power leads, DC Control panel leads, battery and water through holes in the rear panel as shown above and described below:

- a. Connect the genset 2" OD exhaust outlet to the exhaust system of the vessel.
- b. Connect the sea water pump to the vessel's water inlet. Push a 3/4" hose from the vessel's sea water strainer through the lower hole at the bottom left of the rear panel to the sea water pump inlet fitting.
- c. Connect the vessel's fuel lines using Coast Guard approved rubber fuel hoses to the fuel manifold inside the sound shield. The outer fitting is 5/16" 37T JIC fuel suction, and the fitting is 1/4" 37T JIC fuel return.
- d. Connect the DC control harness to the engine harness plug. Pass the harness and plug through the hole at the mid-section of the right side of the rear panel.
- e. Connect the battery leads to the generator set passing the two leads through the second hole above the bottom left side of the rear panel.
- f. Connect the AC output leads from the generator to the vessel's power distribution panel. Pass the two leads through the middle hole on the right side of the rear panel.

Note: This unit features new, non-displaceable penetration grommeting for the AC, DC, and battery cables. Therefore, the fit will be snug.





IF YOU HAVE CHOSEN TO INSTALL A SIPHON BREAK:

Note the pre-installed penetration point in the upper left corner of the non-service side panel. Reference the plumbing diagram in the mounting and exhaust sections of the IM1000 installation manual.

Remove the white plastic hole plugs by pushing them out from the inside and replace with the two rubber grommets (item 17) provided.

CAUTION: GENERATOR SETS WITH WET EXHAUST THAT ARE INSTALLED NEAR OR BELOW THE VESSEL'S WATER LINE MUST USE A SIPHON BREAK TO PREVENT BACKFLOW OR WATER INTO THE ENGINE. THIS BACKFLOW CAN RUIN AN ENGINE AND POSSIBLY SINK THE VESSEL.

- a. Disconnect the hose from the seawater pump output and from the rubber elbow on the expansion tank. Install two lengths of 3/4" hose. The hoses must be of adequate length to allow mounting of a siphon break, a minimum of 12 inches above the vessel's loaded water line.
- b. Pass the seawater pump output hose through the top hole in the panel. The hose from the expansion tank must go through the bottom hole in the panel.
- c. For more information, see the "Exhaust" section of IM1000 Installation Manual.

M843NW3 SOUND SHIELD PACKING LIST

ITEM	DESCRIPTION	NLI P/N	QTY	PACKED
1	JUNCTION BLOCK OFF PLATE ASSEMBLY	06-78110	1	
2	REAR PANEL ASSEMBLY, Includes 06-73108	06-73102	1	
9	BOTTOM SIDE VALENCE ASSEMBLY	06-73104	2	
10	FRONT BOTTOM VALENCE ASSEMBLY	06-73108	1	
11	NON-SERVICE SIDE PANEL ASSEMBLY	06-73107	1	
12	SERVICE SIDE PANEL AFT ASSEMBLY	06-73106	1	
13	FRONT PANEL ASSEMBLY	06-73101	1	
14	SEAL BAR ASSEMBLY	06-73110	1	
15	TOP PANEL ASSEMBLY	00-73103	1	
16	SERVICE SIDE PANEL, FWD ASSEMBLY	00-78105	1	
HARDWAR	E BAG:			
3	M8 FLAT WASHER	15-11000	4	Loose
4	M8 LOCK WASHER	15-00705	4	Loose
5	M8 HEX HEAD CAPSCREW	12-00776	4	Loose
6	1/4" NPT BRASS PIPE NIPPLE	21-00201	2	Loose
7	1/4" NPT BRASS PIPE CAP	21-72241	2	Loose
8	SOUND FOAM, SNORKEL RECEIVER SEAL	55-78174	1	Loose
17	GROMMET, 1-1/8" ID x 1-7/8" OD	00-70083	2	Loose
Packed By	:	Date:		